


***ASCENSION VIRTUOSO***  
***PORTABLE WHEELCHAIR LIFT***  
***5460P MODEL SERIES***  
**MAINTENANCE & REPAIR**  
**MANUAL**




Patented – see [www.ascension-lift.com/patents](http://www.ascension-lift.com/patents)





***ASCENSION VIRTUOSO  
PORTABLE WHEELCHAIR LIFT  
5460P MODEL SERIES***

**MAINTENANCE & REPAIR  
MANUAL**



Copyright © 2023 Ascension, a Division of AGM, Tucson, Arizona

<http://ascension-lift.com>

1-800-459-0400

This document, or parts thereof, may not be reproduced in any form, by any method, for any purpose, without written permission from Ascension.

# TABLE OF CONTENTS

INTRODUCTION.....	1
About This Manual.....	1
Additional Information .....	2
Getting Help.....	2
Contacting Ascension .....	2
SECTION 1 Terminology.....	3
SECTION 2 Routine Maintenance .....	5
2.1 Hydraulic System .....	5
SECTION 3 Mechanical Disassembly and Repair .....	6
3.1 Important Preliminary Information .....	6
3.2 Electrically Isolating the Lift.....	6
3.3 Opening the Machinery Cabinets from the Top.....	7
3.4 Retracting, Removing, and Reinstalling the Safety Skirt .....	8
3.5 Platform Gate Closers .....	14
3.6 Upper and Lower Terminal Switches & Transport Switch .....	15
3.7 Lower Platform Gate Switch.....	17
3.8 Upper Platform Gate Switch.....	19
3.9 Locking Rods and Locking Rod Switch .....	20
3.10 Operating Stations .....	21
3.11 ON/OFF Switch .....	21
3.12 Override Keyswitch .....	22
3.13 Tilt Sensor .....	22
3.14 Alarm.....	23
3.15 Skirt Sensor System.....	24
3.16 Hydraulic Valves .....	27
3.17 Driving Cylinders .....	30
3.18 Interlock Cylinders.....	30
3.19 Windows.....	33
3.20 Skirt Guard .....	34

3.21	Electrical Cord .....	39
SECTION 4 Electrical Testing .....		40
4.1	Control Panel .....	44
4.2	Testing the Switches .....	45
4.3	Testing the Relay Module.....	47
4.4	Testing the Power Supply .....	48
4.5	Testing the Power Relays .....	49
SECTION 5 Lift Compression/Expansion.....		50
5.1	Compressing the Lift .....	51
5.2	Expanding the Lift .....	55
5.3	Verification of Operation.....	61
SECTION 6 Troubleshooting.....		62

# INTRODUCTION

The purpose of this manual is to provide the necessary information to perform maintenance and repairs on the Ascension VIRTUOSO portable wheelchair lift. This manual is intended to be used by skilled technicians who have experience working on electro-mechanical systems and devices. Furthermore, these personnel should be well-versed in standard industrial safety practices and procedures. The appropriate sections should be read through completely before any repairs are begun.

## ***About This Manual***

This manual is divided into six sections:

**Section 1** defines terms that are used throughout the remainder of this manual.

**Section 2** describes the recommended procedures for performing routine maintenance.

**Section 3** covers mechanical repair. This includes component replacement, as well as detailed procedures to disassemble, test, and reassemble major components.

**Section 4** covers electrical testing.

**Section 5** describes how to compress the lift so that it can be rolled through a narrow doorway and then expanded again for normal use.

**Section 6** is a troubleshooting guide. It provides information for locating and correcting any problems with the lift.

## ***Additional Information***

The following sources of information supplement this manual:

**Operating Manual** An Operating Manual is supplied with each lift and includes all the necessary information to set up, break down, store, and transport the lift. It also includes the general safety precautions that should be observed.

**Videos** Various helpful videos may be found on the Ascension website:  
<https://www.ascension-lift.com/lift-setup/>

## ***Getting Help***

If you have a question or problem with the lift, please try to find the solution in this manual. In particular, be sure to review the troubleshooting guide in Section 6. If you are not able to resolve the problem, please contact Ascension as indicated below, making sure that you have the serial number of your lift ready. The serial number can be found on the data plate located inside the platform on the upper left rail. Also, it is recommended that you contact Ascension while in the immediate vicinity of your lift, as this will reduce the time required to properly diagnose the problem.

## ***Contacting Ascension***

Ascension's business hours are 8 a.m. to 5 p.m. Mountain Standard Time, Monday through Friday.

Telephone: 800-459-0400

Fax: 520-881-4983

Email: [sales@ascension-lift.com](mailto:sales@ascension-lift.com)

Website: [ascension-lift.com](http://ascension-lift.com)

Mailing Address: Ascension

Customer Service

PO Box 40020

Tucson, AZ 85717-0020



## SECTION 1 Terminology

To effectively use this manual, you need to be familiar with the following terms. Refer to the figure on the following page for identification of components. Not all components are shown in the figure.

**Access Panels** The four hinged panels that provide access to the machinery cabinets.

**Back End** The upper landing end of the lift.

**Base** The steel frame that rests on the floor and supports the operating mechanism.

**Control Panel** The electrical panel for the lift which contains the power supply, control system relay, and the main power relay. The control panel is located inside the left-hand machinery cabinet.

**Dock Plate** The hinged plate that bridges the gap between the platform floor and the upper landing surface when the platform is at the upper landing.

**Front End** The lower landing end of the lift.

**Lower Platform Gate** The gate that serves the lower landing (ground level).

**Machinery Cabinets** The enclosures in which the lifting and control mechanisms are located. There is one cabinet on each side of the lift. The contents of the machinery cabinets are accessible through the access panels.

**Operating Stations** The controls for raising and lowering the platform. There are three total, each with an up/down rocker switch. The operating station inside the platform also has an emergency stop switch.


**Override Keyswitch** Used with transport mode to install or remove the casters.

**Platform / Lift Car** The compartment in which the passenger rides.

**Safety Skirt** The accordion-style cover which completely encloses the underside of the platform.

**Upper Landing** The stage, platform, or riser that the lift serves.

**Upper Platform Gate** The gate that serves the upper landing, or stage.



## **SECTION 2    Routine Maintenance**

### **2.1    *Hydraulic System***

The fluid level of the hydraulic system should be checked every six months. Verify that the hydraulic fluid in the reservoir (behind right-side access panels) is between the minimum and maximum levels when the platform is at the lower landing.

Inspect the condition of the hydraulic fluid. Change the fluid if it has darkened, appears dirty, or has a strong acrid or burnt odor.

If you need to add hydraulic fluid to the lift, use an ISO 32 grade hydraulic oil, such as Texaco Rando HD32 or 76 Unax AW32 filtered to 10 microns for lifts primarily used indoors. For outdoor lifts use a low-temperature oil such as Amsoil AWF oil. In order to add fluid to the reservoir, first remove the machinery cabinet cover per Section 3.3.

## **SECTION 3     Mechanical Disassembly and Repair**

### **3.1     *Important Preliminary Information***

The repairs in this section are to be performed by a skilled technician who has experience in working on electro-mechanical systems. Furthermore, the technician should be well-versed in standard industrial safety practices and procedures. In the United States of America, electrical safety procedures are established in OSHA's *Lockout/Tagout – Hazardous Energy Sources Standard* (29 CFR 1920.147).

Familiarity with the setup and operation of the lift is required to effectively perform the repairs listed in this section. This information can be found in the *Operating Manual* provided with the lift.

### **3.2     *Electrically Isolating the Lift***

This section describes the procedures for electrically isolating the lift, which is necessary in order to safely perform some of the repairs covered in this manual.

To electrically isolate the lift, perform the following steps in the order listed:

1. Turn the disconnect switch in the power cord to the 'OFF' position. Secure it with a lockout hasp and/or padlock.


OR

1. Remove the lift's power cord from the wall outlet.
2. Attach a DANGER tag to the end of the power cord and lock out the cord according to the procedures established in OSHA's *Lockout/Tagout – Hazardous Energy Sources Standard* (29 CFR 1910.147).
3. Coil the electrical cord and place it inside the platform.

### 3.3 Opening the Machinery Cabinets from the Top

For some of the repairs described in this manual, it is necessary to gain access to a machinery cabinet from the top. The top of either machinery cabinet can be removed by performing the following steps:

1. Remove the window located above the machinery cabinet from its frame. See Section 3.19.
2. Use a T25 Torx tamper-resistant driver to remove the ten (10) flat head screws which hold the cabinet top in place. The top can now be removed from the cabinet. It may be necessary to open an access panel and push from inside the cabinet to pop the top out.




To reinstall the machinery cabinet top, perform the above steps in reverse order.

### 3.4 Retracting, Removing, and Reinstalling the Safety Skirt

The safety skirt consists of two parts: the platform skirt, which guards the platform on three sides; and the gate skirt, which guards the area under the lower platform gate. For some of the repairs described in this manual, it is necessary to gain access to components normally hidden behind the skirt. In most cases, only a small portion of the skirt may need to be retracted; however, sometimes it may be necessary to remove the whole skirt.

**Gate Skirt:** To remove the *gate skirt*, perform all of the following steps. If the skirt only needs to be retracted, performing only Step 3 will provide access to many of the components behind the skirt. Refer to the figure below for the location of the fasteners referenced in each step.




1. Use a 5/16" wrench to remove the three (3) hex head screws that secure the skirt to the skirt base. These screws are located on the top side of the skirt base.
2. Using any operating station, raise the platform until the platform floor is approximately 24" [610 mm] off the ground.

3. Use a T25 Torx tamper-resistant driver to remove the three (3) screws that secure the skirt to the lower platform gate.
4. Use a 5/32" hex key to remove the two (2) button head cap screws and washers that secure the skirt guide tubes to the skirt base. Hold the skirt guide tubes stationary with pliers if necessary while removing the screws.
5. Use a T25 Torx tamper-resistant driver to remove the four (4) screws (two (2) on each side) that secure the skirt guide tube brackets to the lower platform gate and pull the brackets downward, out of the gate. The skirt can now be removed from the gate.


To reinstall the *gate skirt*, perform the above steps in reverse order.

**Platform Skirt:** To remove the *platform skirt*, perform the following steps. Also see [Virtuoso Compression Video](#) from the Ascension website which includes skirt removal. Performing steps 2 & 3 will provide access behind the skirt without fully removing it.

1. With the platform about 15" [380 mm] off the ground, remove the (32) T25 Torx tamper-resistant head screws that secure the sides of the skirt to the platform at the top and to the lift base at the bottom.
2. Use a 5/16" combination wrench to remove the four (4) hex head screws that secure the top of the skirt to the platform, one (1) at each corner. Remove the small skirt support brackets that are freed when these screws are removed.
3. Remove T25 Torx tamper-resistant head screw that secures the back of the skirt to the base.
4. Remove the (2) 5/16"-18 screws from the lift frame just above the ball bearing slides.
5. In the back, retract the skirt around the ball-bearing slides as shown in the figure at the top of the following page. You will need to hold each skirt panel approximately horizontal to move it past the restraining tab.



6. Push the ball bearing slide release levers toward the right side of the lift and then pull downward on the skirt guard to separate it from the platform.
7. At the front of the skirt, use pliers or a similar tool to turn the skirt guide tubes counterclockwise until they release from the studs in the base. You will need to lift the corners of the skirt to gain access to the skirt guide tubes.



FRONT RIGHT CORNER OF THE LIFT SHOWN

8. Retract the skirt guide tubes through the slots in the skirt. The skirt is now free of the lift. Use extreme care to support the skirt in its natural position as much as




possible while moving it. A minimum of two (2) people is recommended for moving the skirt.

To reinstall the *platform skirt*, perform the following steps. Also see [Virtuoso Compression Video](#) from the Ascension website which includes skirt reinstallation. If necessary, refer to the figures in the skirt removal instructions above for identification of skirt components.


**⚠ CAUTION!**

***In the following step, stay clear of the platform when it is moving to avoid any pinching and/or crushing hazards.***


1. With the platform about 15" [380 mm] off the ground, move the skirt into position around the platform, roughly where it will be located when installed on the lift. Use extreme care to support the skirt in its natural position as much as possible while moving it. A minimum of two (2) people is recommended for moving the skirt.
2. At both front corners of the platform, lift the skirt guide tubes upward, move the skirt into place, and insert the guide tubes through the slots in the skirt. Then turn the guide tubes clockwise onto the base studs, using pliers to tighten them.
3. In the back, reinstall the skirt guard onto the lift by performing the following steps. Refer to the figure at the top of the following page as necessary.
  - a. Position the skirt guard underneath the ball bearing slide rails at the back of the lift, aligning the skirt guard slide rails with the platform slide rails.
  - b. Move the skirt guard upward, while making sure that the skirt guard tabs slide behind the retaining flanges on the platform, and that the slide rails on the skirt guard lock into the slide rails on the platform.
  - c. You will feel and hear a "click" when the ball bearing slide rails engage each other, and the skirt guard will be held in place. If the skirt guard was installed correctly, the guard cannot be pulled away from the lift. If this is not the case, use the release levers to release the skirt guard and then reinstall it, taking care to slide the skirt guard tabs behind the retaining flanges on the platform.
  - d. Reinstall the 5/16"-18 screws into the holes in the lift frame just above where the ball bearing slide rails enter the frame.



4. Lift the skirt upward on both sides of the skirt guard until the skirt slips past the restraining tabs on the ball bearing slides as shown in the figure below. The restraining tab must catch the skirt on the 7th panel down from the top of the skirt.




5. Reinstall two (2) or three (3) T25 Torx tamper-resistant head screws on each side of the platform to secure the top of the skirt loosely to the platform.
6. Use a 5/16" combination wrench to reinstall the four (4) hex head screws that secure the top of the skirt to the platform, one (1) at each corner. Be sure to install the skirt support brackets between the skirt and the platform frame. See the figure below.



7. Reinstall the remainder of the (32) T25 Torx tamper-resistant head screws that secure the sides of the skirt to the platform at the top and to the lift base at the bottom.
8. Reinstall the T25 Torx tamper-resistant head screw that secures the back of the skirt to the base.

### 3.5 Platform Gate Closers

To make a platform gate close faster, turn the gate closer counterclockwise, 1/2 rotation at a time. To make a platform gate close slower, turn the gate closer clockwise, 1/2 rotation at a time. See the figure below.



### **3.6 Upper and Lower Terminal Switches & Transport Switch**


The upper stop mechanism serves a few different functions, but gets its name since its main purpose is to stop the platform at the upper landing. The upper stop mechanism is located in the left-hand machinery cabinet and contains the upper terminal switch, the ball plunger, the lower terminal switch, and the transport switch. For instructions on adjusting the platform stop height, see "Setup Instructions" in the *Operating Manual*.

**Upper Terminal Switch:** The normally closed (NC) contacts are used on this switch. Whenever the switch is actuated (contacts opened), the lift will not run up. The roller arm on the switch is actuated by the actuator ramp on the adjacent linkage. The assembly is factory-set such that the upper terminal switch actuates at the same time as when the ball plunger "clicks" into the ball plunger slot (see next section). To finely adjust the actuation point of the switch, use a 1/16" hex key to adjust the set screw at the roller arm base.

**Ball Plunger:** The ball plunger's only purpose is to "click" into the ball plunger slot right as upper terminal switch actuates in order to simplify positioning the upper terminal switch and setting the platform stop height. After the stop height is set, it has no bearing on operation. When the two are perfectly synched, the height that the platform automatically stops at during normal use will exactly match the platform height from when the stop height was set via the height adjustment knob and ball plunger. When not synched, the platform will stop above or below the intended stop location set per the setup procedure. The ball plunger force (the strength of the "click") may be adjusted by screwing the threaded plunger assembly in or out and locking it in place with the nut. The ball plunger position (relative to the actuation point of the upper terminal switch) may be adjusted by adjusting the position of the bracket it is mounted to. However, please note that adjusting this bracket simultaneously adjusts the position of both the ball plunger and the lower terminal switch (see next section).


**Lower Terminal Switch:** When this normally open (NO) switch is actuated, it allows the motor to fully engage/disengage the lower platform gate lock, functioning as a bypass to the locking rod switch (Section 3.9). Accordingly, the lower terminal switch is factory-set to be actuated when the platform is within 2" of the lower landing. As the platform cannot go any lower than floor level, this switch does not stop the motor at the lower landing and instead runs it for few seconds in order to unlock the lower gate and relevel the platform. This switch is actuated by the adjacent linkage (see image below). The switch position may be adjusted relative to its mounting bracket. The mounting bracket position may be adjusted as well, though bracket adjustments will simultaneously adjust both the ball plunger and the lower terminal switch positions. To check the switch setting, open the lower platform gate and, while manually actuating the lower platform gate switch (Section 3.7), run the lift up and ensure that it stops automatically within 2".

**Transport Switch:** This normally open (NO) switch is actuated by adjusting the height adjustment knob to "TRANSPORT". The transport switch is used in conjunction with the override keyswitch (Section 3.12) to install/remove the casters during setup. The switch position may be adjusted relative to its mounting plate.



### 3.7 Lower Platform Gate Switch

The lower platform gate switch senses whether the lower platform gate is open or closed. The switch is located on the platform at the hinge side of the gate, about 12" [305 mm] from the floor. Refer to the right-hand figure below. The switch has wires connected to its normally open (NO) and common (COM) terminals.



The gate switch is in correct adjustment if the lift will operate only when the gate is closed. The gate is considered to be closed if the upper locking rod in the gate engages in the lock cutout as the platform moves off the ground. See the left-hand figure above for the location of the lock cutout.

If the platform can be raised off the ground with the gate open far enough for the locking rod to fall outside of the lock cutout, then the switch probably needs to be recessed further into the platform wall. (In this case, the platform will not go higher than 2" [50 mm] off the ground.) If the platform stops just after it begins to rise off the ground, then the switch may need to be extended further out of the platform wall.

You will need to access the back of the switch in order to adjust, test, or replace it. To do so, retract the upper front corner of the platform skirt away from the platform. If necessary, see Section 3.4 for instructions on retracting the skirt.

The switch is held in place by two (2) 14 mm nuts. To adjust the switch (i.e., to extend it or recess it), use a 14 mm wrench or socket to loosen the outer nut, move the inner nut as necessary, and then retighten the outer nut. To remove the switch, use a 14 mm wrench or socket to remove the outer nut and then pull the switch out of its mounting hole.




### 3.8 Upper Platform Gate Switch

The upper platform gate switch senses whether the upper platform gate is open or closed. The switch is a refrigerator-style switch located on the hinge-side of the gate. The switch is of the normally open (NO) type.


The lift should not be able to operate unless the upper platform gate is closed (the handle does not protrude beyond the back edge of the lift). The switch is not adjustable, but the actuator for the refrigerator-style switch may be adjusted. To adjust the switch actuator, insert a screwdriver or similar tool into the hole in the actuator and then carefully bend it in or out.

To remove the refrigerator-style switch, remove the right-hand machinery cabinet cover (see Section 3.3). With the platform at least 24" [610 mm] off the ground, depress the tab on the far side of the switch body and push the switch out of its mounting hole from inside the platform wall.



### 3.9 Locking Rods and Locking Rod Switch

The two hydraulically driven locking rods (interlock) extend from the lower platform gate into the platform sides to physically lock the gate during travel. The locking rod switch senses if the top locking rod has successfully engaged and locked the gate. Before the platform has moved 2" [50 mm] off the ground, the platform will stop if the locking rod has not successfully engaged (see Lower Terminal Switch from Section 3.6). The switch is located in the front strike-side corner of the platform, behind the skirt (see Section 3.4 for detailed instructions on retracting the skirt). The switch is of the normally open (NO) type.




The locking rods are hydraulically driven, so either the motor or the hand pump must be used to move them. The lift is plumbed such that the locking rods must extend before the platform can begin to raise and will only retract after the platform has reached the ground. Accordingly, the motor will run for a few seconds after reaching the lower landing to retract the locking rods. To manually unlock the lower platform gate after reaching the lower landing, use the hand pump to pump down. It is recommended to first turn off the main shut-off valve (section 3.16) as this will make the process easier. Turning off the main shut-off valve also allows the hand pump to be used to retract the locking rods even when the platform is raised. *Electrically isolate the lift (section 3.2) before placing any body parts under the platform floor.*

### 3.10 Operating Stations

Operating stations are the controls for raising and lowering the platform. There is an operating station for the lower landing, the platform, and the upper landing. The operating station inside the platform has an emergency stop switch. The emergency stop switch immediately stops the lift until it is manually reset.

To gain access to any of the up/down operating switches or the emergency stop switch, remove the screws fastening the mounting plate.



### 3.11 ON/OFF Switch

The ON/OFF switch is used to enable/disable the lift. When “OFF”, this switch will cut all power to the lift control system, preventing the lift from operating. This switch is located on the outer electrical panel (see Section 4.1) behind the access panels in the left-hand machinery cabinet.

### 3.12 Override Keyswitch

The override keyswitch is used in conjunction with the transport switch (Section 3.6) and an operating switch to raise or lower the platform with the lower platform gate open when installing or removing the casters. The switch is of the "OFF-Momentary ON" type, and can be tested using a standard multi-meter.


To remove the keyswitch, first remove the operating station on the lower landing end of the lift (see Section 3.10). Then use a 7/8" wrench to remove the nut that holds the keyswitch in place. Finally, use a screwdriver to disconnect the harness terminals and then pull the keyswitch out of the switch plate.

To reinstall the keyswitch, perform the above steps in reverse order. The harness wires are interchangeable.

### 3.13 Tilt Sensor

The tilt sensor is located next to the height adjustment mechanism in the left-hand machine cabinet.


The tilt sensor is used to disable lift operation when the lift is set on an incline greater than 5%. The Fredericks brand switch has an external light that is green when level (lift operation enabled) and red when out of level (lift operation disabled).



### 3.14 Alarm

The lift is equipped with a battery-powered audible alarm that sounds when the emergency stop button is pressed. To test, press the emergency stop button. Reset the emergency stop button to turn off the alarm.


If the alarm does not sound when the emergency stop button is pressed, the alarm battery may need to be replaced. The battery is located just behind the alarm buzzer, which is mounted at the top left corner of the lower landing end of the lift. Remove the alarm assembly from the front of the lift to access the battery for replacement. Replace battery with style MN21, 23A/KE23A-1, or A23.





### 3.15 Skirt Sensor System

The skirt sensor system halts the motion of the platform when an object or person pushes the safety skirt on the long sides of the lift inward more than 3" [76 mm]. One sensor assembly is located on each of the two hydraulic cylinders and consists of two extension springs that run the length of the hydraulic cylinder and two sensor switches that are actuated by the movement of the springs.

- See the figure below for the locations of the sensor switches. To gain access to the sensor switches, you can:
  - Retract the safety skirt as described in Section 3.4.
  - Move the platform away from the lower landing with the lower platform gate open (while overriding the locking rod switch and lower platform gate switch) until the sensor switches can be accessed from underneath the platform floor.  
*Electrically isolate the lift (section 3.2) before placing any body parts under the platform floor.*
  - Open a machinery cabinet from the top as described in Section 3.3.



- To shift the position of a sensor switch, loosen the hose clamp that holds it in place, shift the clamp, and then retighten it.
- To remove a switch:
  - Mark the location of the hose clamp on the hydraulic cylinder so it can be put back in the same place.
  - Remove the wires from the switch terminals.
  - Remove the hose clamp and pull the assembly free from the hydraulic cylinder.
  - Remove the two (2) 6-32 x 7/8 button head cap screws that secure the switch to the bracket and hose clamp.
- To install a switch:
  - Refer to the figure on the following page for the orientation of the switch and bracket to the hose clamp. Note that the assemblies on the right and left side are mirror images of each other.
  - Be careful not to over tighten the two (2) 6-32 x 7/8 button head cap screws that secure the switch to the bracket and hose clamp, as this could crack the switch case.
  - The pre-travel on the switch should be minimized such that the switch audibly "clicks" (its contacts close) just as the switch actuator is starting to be depressed. If necessary, adjust the pre-travel on the switch actuator by turning the small set screw at the base of the actuator with a 1/16" hex key.
  - When the switch assembly is installed correctly on the hydraulic cylinder, it will halt the movement of the platform when the skirt is pushed inward more than 3" [76 mm]. This generally requires that the switch actuator be positioned about .060-.090" [1.5-2.25 mm] from the extension spring that actuates it.
  - The hex head on the hose clamp should be oriented such that it does not impede the movement of either extension spring and does not contact the sidewall of the platform as the platform descends.
  - The wiring harness should be connected to the normally closed (NC) and common (COM) terminals of the switch.






### 3.16 Hydraulic Valves

The various hydraulic valves are located inside the right-hand machinery cabinet behind the access panels. For additional access, the top of the machinery cabinet may be removed (see Section 3.3).

Refer to the following instructions for adjusting or removing any of the hydraulic valves. It is recommended to place paper towels below the component to be removed to catch the several ounces of hydraulic fluid that will drip as the component is removed. Refer to the following figures for component identification.

#### **⚠ WARNING!**

***The platform MUST be either at the lower landing or secured in place before the COUNTERBALANCE VALVE or PILOT-OPERATED CHECK VALVE is loosened or removed. Failure to do so could result in the platform dropping and/or high-pressure hydraulic oil leaks.***



**Pilot-Operated Check Valve:** This valve keeps the lift base raised when the lift is on its casters. This valve cannot be adjusted. Use a 7/8" wrench to remove the valve from the manifold. When reinstalling the valve, torque it to 25-30 ft-lbs [19-22 N\*m].

**Counterbalance Valve:** This valve keeps the platform raised when the motor is not running. If the platform "bounces" as it descends while fully loaded, then the adjustment screw on this valve may need to be tightened clockwise a 1/4 turn at a time until the "bouncing" has been eliminated. To remove this valve, use a 7/8" wrench. When reinstalling the valve, torque it to 18.5-22.0 ft-lbs [13.6-16.2 N\*m].

**Directional Valve:** This valve directs the hydraulic fluid flow to run the lift up or down. This valve is normally operated by the solenoid, but can be manually overridden with the valve button. The default (un-powered/un-overridden) position is for flow that causes the platform to go up. This valve cannot be adjusted. If necessary, this valve can be removed with the platform raised. However, retighten immediately should the platform start to descend during removal, which indicates a faulty counterbalance valve. To remove the valve, first disconnect the solenoid wires, then turn the black button clockwise to remove it and the solenoid. Use a 7/8" wrench to remove the valve from the manifold. When reinstalling the valve, torque it to 18.5-22.0 ft-lbs [13.6-16.2 N\*m].


**Hand Pump:** The hand pump cannot be adjusted. The hand pump can be removed while the platform is not at the lower landing provided that the counterbalance valve is working correctly. However, if the platform starts to descend while you are turning the pump out of the manifold, immediately tighten it back into the manifold; the counterbalance valve is malfunctioning and must be replaced (with the platform at the lower landing). Use a 1-1/4" wrench to remove the hand pump from the manifold. When reinstalling the hand pump, torque it to 25-30 ft-lbs [19-22 N\*m].

**Pump Check Valve:** This valve functions as a backup to the counterbalance valve to keep the platform raised when the motor is not running. This valve cannot be adjusted.

**Relief Valve:** This valve sets the maximum pressure that can be developed in the hydraulic system. This is factory-set to 900 psi. To adjust, remove the cap and tighten the screw to increase relief pressure, or loosen the screw to decrease relief pressure.

**Main Shut-Off Valve:** This valve is a brass ball valve with a T-style handle located beneath the hydraulic pump. When closed, it blocks fluid flow to the cylinders and only allows flow to the locking rods. Turn handle horizontal to close or vertical to open.

**Interlock Relief Valve (for Locking Rods):** This in-line valve is housed within a long, hexagonal casing. It is located behind the right-hand access panels for lifts with a left-handed lower platform gate and at the back, bottom left corner of the platform for lifts with a right-handed lower platform gate. When lowering the platform, the purpose of this valve is to block flow that would retract the locking rods until the platform has reached the ground, at which point enough pressure can be developed to open this relief valve and begin retracting the locking rods. This valve cannot be adjusted.



**HYDRAULIC DIAGRAM**

### **3.17 Driving Cylinders**

The two double-acting driving cylinders are responsible for physically raising and lowering the platform. The cylinders are in series with the first being the “master” cylinder (right side of lift) and the second being the “slave” (left side of lift). The cylinders include bypass ports that allow hydraulic fluid to pass through them when fully retracted to resynchronize the two cylinders with each other such that the platform raises level each cycle. If the platform does not raise level with the motor (the platform will not raise level with the hand pump), the starting extension point (maximum retraction) of each cylinder may be finely adjusted via the cylinder stop screw located directly beneath where each cylinder rod attaches to the lift base. The cylinder stop screws are factory-set and should not normally need to be adjusted in the field.


### **3.18 Interlock Cylinders**

The two hydraulic interlock cylinders physically extend and retract the locking rods (Section 3.9). The cylinders are mounted behind the lower platform gate skirt, one at the bottom and the other higher up. Two hydraulic hoses are routed into the gate on the hinge-side to serve these cylinders.

To remove and replace the interlock cylinders, perform all of the following steps. *ALWAYS make sure that the lift platform is at the lower landing before detaching any hydraulic hoses. Otherwise, there will be hydraulic pressure in the system.*

1. To replace the cylinders, first remove the gate skirt as instructed in Section 3.4.
2. Position the platform with the floor approximately 10” [254 mm] off the ground with the lower platform gate open. The lift may be raised with the gate open by manually actuating both the locking rod switch (Section 3.9) and the lower platform gate switch (Section 3.7), or by using the hand pump.

3. Remove the lower hinge bolt that secures the skirt base to the lift base: Loosen the cap head screw in the shaft collar using a 7/64 hex key, and then turn the hinge bolt out with a 7/32 hex key while using a standard screwdriver blade to keep the shaft collar from rotating.



4. Use a 1/2" wrench or socket to remove the three (3) bolts that secure the top of the scissor locking mechanism to the gate. Note the position of the bolts in the slots so that the mechanism may be reinstalled in the same position later.
5. Remove the scissor locking mechanism from the gate, pulling the hinge side out first until the locking rod can be pulled through the gate cutout. The easiest way to do this is, with the lower platform gate almost fully closed, to lift up the skirt base until the scissors are collapsed, and then pull the base out toward you. DO NOT disconnect the hydraulic hoses at this time.
6. Lower the lift platform all the way to the lower landing, taking care not to crush or damage the interlock mechanism. Keep running down until the locking rods are retracted.
7. Use two 9/16" wrenches to disconnect the hydraulic hoses from the cylinder(s): use one wrench to turn the hose fitting and the other wrench to keep the hose from twisting. You may get some hydraulic fluid leakage from the hoses when you disconnect them.
8. Use a 5/32" hex wrench to remove the bracket that holds the cylinder to the mechanism, and disconnect the cylinder clevis from the locking rod.
9. Install the replacement cylinder(s) using the same tools that were used for removing the old one(s) and reconnect all hoses.
10. After confirming that all hose connections are tight, position the platform with the floor approximately 10" [254 mm] off the ground, and then re-install the locking mechanism into the gate using the three (3) removed bolts.

11. Loosely secure the skirt base to the base frame, raising the platform further if necessary.
12. Lower the platform to the lower landing and close the front gate. Cycle the lift vertically 4-5 times so that the locking mechanism fills with oil. Verify that the lock remains closed while the lifting platform descends, performing additional cycles until it does, if necessary.
13. Verify that the gate is hanging at the correct height, not angled too far up or down. If the gate is hanging down (sagging), loosen the three (3) bolts that hold the scissor mechanism to the gate and shift the mechanism toward the hinge side of the gate before re-tightening the bolts. You can shift the position of the mechanism by wedging a standard screwdriver between the end of the top mechanism member and the side of the gate's kick panel, and then using the screwdriver as a lever. If the gate is hanging too far up, move the mechanism toward the latch side of the gate instead.
14. Reinstall the gate skirt as instructed in Section 3.4 and re-secure the skirt base tightly to the base frame.
15. Cycle the lift platform up and down several times with the lower platform gate closed to confirm correct operation.


### 3.19 Windows

All standard windows are made of high impact strength acrylic sheet. The windows are pinched in the channel of a glazing strip which is attached to the lift frame with screws. See the figure below.

To remove a window, remove each of the screws attaching the four glazing strips to the lift's exterior. The window and strips can then be removed as a single unit.

To reinstall a window, position the window assembly in its original installation orientation and reinstall screws. Note that in some locations there may be a gap between the bottom of the glazing strip channel and the lift frame to allow clearance for the fillet welds at the corners of the frame; this is normal.

Clean windows using a soft antistatic cloth and water mixed with a mild, non-abrasive detergent. Scuffs and scratches may be removed with plastic polish (Ex: Novus #2 or #3 plastic polish).




### 3.20 Skirt Guard

The skirt guard is located on the upper landing side of the platform, below the gate. The skirt guard blocks the dock plate from deploying while the lift is fully lowered, but slides out of the way as the platform moves away from the lower landing.

To detach the skirt guard from the lift and safety skirt, perform the following steps:

1. Raise the platform so the platform floor is at least 15" [380 mm] off the ground.
2. Detach the top of the protective skirt from the long sides of the platform by removing the ten (10) T25 Torx tamper-resistant head screws that secure each side.
3. Use a 5/16" combination wrench to remove the two (2) hex head screws that secure the top of the skirt to the platform on the upper landing side, one (1) at each corner. Remove the small skirt support brackets that are freed when these screws are removed.
4. Remove the (2) 5/16"-18 screws from the lift frame just above the ball bearing slides.
5. Retract the skirt around the ball bearing slides as shown in the figure below. You will need to hold each skirt panel approximately horizontal to move it past the restraining tab.







6. Push the ball bearing slide release levers as shown in the figure on the previous page and then pull downward on the skirt guard to separate it from the platform.
7. Remove the three (3) hex head screws that secure the skirt to the skirt guard using a 5/16" wrench.
8. Use a 3/32 hex key to remove the two (2) 8-32 x 3/16 button head cap screws that secure the ball bearing slide rails to the skirt guard. The guard can now be freed from the safety skirt.

To reinstall the skirt guard, perform the following steps. If necessary, refer to the figures in the skirt guard instructions above for identification of components.


1. Thread the ball bearing slide rails through the skirt slots and the rectangular cutouts in the skirt guard and secure them in place using the two (2) 8-32 x 3/16 button head cap screws. The screws should be approximately centered in the horizontal slots in the ball bearing slide rails.
2. Use a 5/16" wrench to secure the skirt to the skirt guard with the (3) hex head screws removed in Step 6 above.
3. Position the skirt guard underneath the ball bearing slide rails on the platform, so that the slide rails on the skirt guard line up with the slide rails on the platform.
4. Move the skirt guard upward, while making sure the skirt guard tabs slide behind the retaining flanges on the platform, and that the slide rails on the skirt guard lock into the slide rails on the platform. See the figure at the top of the following page.
5. You will feel and hear a "click" when the ball bearing slides engage each other, and the skirt guard will be held in place. If the skirt guard was installed correctly, the guard cannot be pulled away from the lift. If this is not the case, use the release levers to release the skirt guard, and then reinstall it, taking care to slide the skirt guard tabs behind the retaining flanges on the platform.
6. Reinstall the 5/16"-18 screws into the holes in the lift frame just above where the ball bearing slides enter the frame.



7. Lift the skirt upward on both sides of the skirt guard until the skirt slips past the restraining tabs on the ball bearing slides as shown in the figure below. The restraining tab must catch the skirt on the 7th panel down from the top of the skirt.



8. Reinstall two (2) or three (3) T25 Torx tamper-resistant head screws on each side of the platform to secure the top of the skirt loosely to the platform.
9. Use a 5/16" combination wrench to reinstall the two (2) hex head screws that secure the skirt and skirt support brackets to the platform, one (1) at each corner. Be sure to install the skirt support brackets between the skirt and the platform frame. See the figure below.




10. Reinstall the remainder of the ten (10) T25 Torx tamper-resistant head screws that secure the sides of the skirt to the platform.

To remove the portion of a ball bearing slide that is mounted to the platform:

1. Complete steps 1-6 in the instructions above for removing the skirt guard from the platform.
2. Use a blade or small standard screwdriver to pry the two (2) dress plugs out of the platform frame in the corner in which you are removing the ball bearing slide. See the figure on the following page.

3. Use a Phillips screwdriver to remove the two (2) 8-18 x 3/8 self-tapping pan head screws that are now accessible. You may need to shift the position of the movable portion of the ball bearing slide to expose the screws. Be sure to catch the screws as they are removed.

To install a ball bearing slide into the platform frame, reverse the above instructions. Be sure to install the two (2) 8-18 x 3/8 self-tapping pan head screws through the ball bearing slide holes indicated in the figure below. It is recommended that you mark the correct holes with a marker on the ball bearing slide before attempting to install the slide inside the platform frame so that it is clear which mounting holes are correct.



### **3.21 *Electrical Cord***

The power/electrical cord is used to connect the lift to facility power.

**GFCI:** The electrical cord contains a GFCI on the plug. The “Test” button may be used to test the GFCI to make sure it trips and disconnects power to the lift. Press the “Reset” button to restore power to the lift.

**Disconnect Switch:** The disconnect switch is mounted in a box on the lift electrical cord, near the plug. This switch may be used to turn on/off power to the lift. The disconnect switch is lockable in the “OFF” position.

“I” = ON

“O” = OFF


## SECTION 4 Electrical Testing

This section contains information that will enable a skilled and experienced electrician to service the lift. The electrical and logic diagrams for the lift is shown on the following pages.

### **⚠ CAUTION!**


***When working on any part of the electrical system, industrial electrical safety practices should be rigorously adhered to, including:***

- ***Danger Tags: While repairs are underway, a danger tag should be attached to the plug of the electrical cord to advise personnel that the lift is being serviced. Additionally, the plug should be locked out according to the procedures established in OSHA's Lockout/Tagout – Hazardous Energy Sources Standard (29 CFR 1910.147).***
- ***Two-man rule: As a minimum, two (2) people should be present while repairs and tests are being performed.***
- ***Do not leave the lift unattended with the plug connected to the service outlet while the electrical system components are exposed. Remove the plug if it is necessary to leave the lift, no matter how briefly.***
- ***Be cognizant as to the electrical status of the lift (i.e., whether it is powered or not). When in doubt as to whether a circuit or component is powered, test it first!***



(110057 Rev N ELECTRICAL DIAGRAM.vsd)

### SIMPLIFIED ELECTRICAL DIAGRAM




### **SMART RELAY MODULE LOGIC**

#### **Notes:**

The logic diagram above does not include any of the timers or more complicated components of the logic circuit. Rather, it only shows the contacts that must be maintained for the platform to run up or down. To use the logic diagram, start at the left and work towards the right. If there is a continuous path to a given endpoint (Ex: Q1), then the smart relay will activate that given endpoint/component.



Ascension Wiring Diagram:  
Virtuoso 5460P Relocatable Lift



**FULL ELECTRICAL DIAGRAM**


(Contact Ascension for electronic color copy of 5460P full electrical diagram).

(20230530 Virtuoso Full Wiring Diagram - 5460P Series.vsd)

## 4.1 Control Panel

The electrical panel can be accessed through both access panels in the left-hand machinery cabinet. If additional access space is needed, the top of the left-hand machinery cabinet can be removed (refer to Section 3.3 for instructions).

Refer to the figure below for identification of the major components on the electrical panel.



ELECTRICAL PANEL & MAJOR COMPONENTS  
WIRING HARNESES AND CONNECTORS NOT SHOWN

## 4.2 Testing the Switches

When troubleshooting the electrical system, it is recommended to begin by testing at the Smart Relay Module to determine the present state of each individual safety circuit. The control system operates on 24 VDC. Before performing any checks at the relay module, verify that the module itself is receiving power (refer to Section 4.3). If the module is receiving power, then the function of the lift's switches can be verified by testing for 24 VDC between ground (M) and each of the smart relay inputs (I1 – I8) continuity across the relay module's contacts as shown in the following table.

Circuit Components	Relay Module Contacts	Circuit is closed (meter reads 24VDC) when:	Circuit is open (meter reads ~0VDC) when:
Operating Switch (Down)	I1-M	"DOWN" is pressed	"DOWN" is not pressed
Operating Switch (Up)	I2-M	"UP" is pressed	"UP" is not pressed
Skirt switches (4x)	I3-M	Skirt hangs freely; not pushed in	Object pushing in on skirt
Gate Switches	I4-M	Gates are closed	Either gate is open
Tilt Sensor	I5-M	Lift is on level ground	Lift is not on level ground
Locking Rod Switch	I6-M	Lower platform gate is locked	Lower platform gate is unlocked
Lower Terminal Switch	I7-M	Platform is less than ~2" [50 mm] off the ground	Platform is more than ~2" [50 mm] off the ground
Upper Stop Switch	I8-M	Switch is not engaged by upper stop mechanism (platform is not at the upper landing)	Switch is engaged by upper stop mechanism (platform is at the upper landing)

(The following is only applicable during setup when installing/removing the casters where the lower platform gate is open and unlocked)

Transport Switch	I4-M	Height adjustment knob is in transport location, upper platform gate is closed, and "I6" circuit is closed.	Height adjustment knob is not in transport location, and/or upper platform gate is not closed, and/or "I6" circuit not closed.
Override Keyswitch	I6-M	Override keyswitch is turned "on"	Override keyswitch is not turned "on"

Once a given safety circuit has been identified as the problem, the switches and wire connections in that circuit may be tested. Individual switches may be tested for continuity across the switch contacts. Note that the lift should be disconnected from power when testing for continuity. See the table below for information on the type and corresponding manual section for each switch.

Switch	Type	Section
Transport Switch	SPST, NO	3.6
Lower Terminal Switch	SPST, NO	3.6
Upper Terminal Switch	SPDT, NC circuit used	3.6
Lower Platform Gate Switch	SPDT, NO circuit used	3.7
Upper Platform Gate Switch	SPST, NO	3.8
Locking Rod Switch	SPST, NO	3.9
Emergency Stop Switch	Push-to-break	3.10
Up/down Operating Switch	(Mom. On)-Off-(Mom. On)	3.10
ON/OFF Switch	On-Off	3.11
Override Keyswitch	Off-(Mom. On)	3.12
Tilt Sensor	SPDT, NC circuit used	3.13
Skirt Sensor (4x)	4x SPDT, NC circuit used	3.15

### **4.3 Testing the Relay Module**

The relay module (Smart Relay) is located on the electrical panel. See Section 4.1.

A green light on the relay module indicates that it is receiving power and is ready for use. Note that the relay module requires 6-8 seconds to initialize after it receives power (i.e., the lift is plugged in), during which time the relay light is red. Always give the module time to initialize before performing any testing on it.

To test the function of the relay module, refer to the smart relay module logic diagram at the beginning of SECTION 4.

If the relay module is not receiving power, check for and correct the following conditions as necessary:

1. The lift is not plugged in. Plug the lift in.
2. The service outlet does not have power. Plug the lift into an outlet that does have power.
3. The GFCI on the power cord has been tripped. Reset the GFCI.
4. The in-line disconnect switch is "OFF". Turn on the disconnect "ON".
5. The power supply is not supplying 24 VDC. Refer to Section 4.4 to check it.
6. There has been a wiring harness or connector failure. See the Electrical Diagrams at the beginning of SECTION 4 to continue troubleshooting, or contact Ascension.
7. The E-Stop is pushed in and the alarm is active. Reset the E-Stop.
8. The ON/OFF switch is "OFF". Turn the switch "ON".

#### **4.4    *Testing the Power Supply***

The power supply converts the 120 VAC<sup>†</sup> input power from the facility to 24 VDC which is used to power the entire lift control system. The power supply is located behind the inner electrical panel. See Section 4.1. The lift must be plugged in and turned on to perform the following tests.

To confirm that the power supply is receiving power, verify that the green light on the power supply is illuminated; this may be viewed by removing the lower landing operating station plate. Otherwise, confirm that the internal power outlet that the power supply is plugged into is outputting 120 VAC<sup>†</sup>.

To confirm that the power supply is outputting power, disconnect the power supply output at the circular connector behind the inner electrical panel and test for a 24 VDC drop between the exposed metal on the inside and outside of the cylindrical male connector. If the power supply is receiving 120 VAC<sup>†</sup> but is not outputting 24 VDC, then the power supply must be replaced.

---

<sup>†</sup> Electrical ratings may differ on lifts outside the USA. Check lift data plate for electrical ratings.

## **4.5 Testing the Power Relays**

The power relays connect/disconnect 120 VAC<sup>†</sup> power to the motor to cause the lift to run/stop. When 24 VDC is applied to the input-side of the relays, the output-side relay contacts close and supply power to the motor. See Section 4.1 for identification of the power relays. The lift must be plugged in and turned on to perform the following tests.

### **Checking for AC Supply Power**

While the motor is not running, 120 VAC<sup>†</sup> should be present across Power Relay 1 terminal '11' and Power Relay 2 terminal '11'. If not, check the upstream AC power connections. Alternatively, confirm power by manually overriding the power relays.

### **Manually Overriding the Power Relays**

***CAUTION: The following test may cause the lift to move.***

To manually override the power relays, push the small override buttons on the front of both relays simultaneously. Normally, will cause the motor to run and the lift to move.

Releasing either override button should cause the lift to stop. If releasing the override button on either relay does not cause the lift to stop, that relay must be replaced.

### **Replacing the Power Relays**

To replace a power relay, first electrically isolate the lift according to the procedures in Section 3.2. Next, push the metal hold-down clip down off the top of the relay and pull the relay out of its socket. Insert the new relay into the socket and pull the hold-down clip back onto the top of the relay to secure it.

---

<sup>†</sup> Electrical ratings may differ on lifts outside the USA. Check lift data plate for electrical ratings.

## SECTION 5    Lift Compression/Expansion

The VIRTUOSO lift can be compressed to a width of 33" in order to move it through a narrow doorway. This section describes the procedures for compressing the lift and then expanding it again. A toolkit is available for purchase from Ascension that contains several of the tools required for the process; however, the owning facility may use its own tools in place of the kit if desired.

The following tools are required for the compression/expansion process. Items with an asterisk (\*) are included in the Ascension Toolkit.

- Operating Manual
- 6" [150 mm] length of duct tape or similar
- Safety glasses for all personnel
- Phillips screwdriver (power screwdriver preferable)
- Standard screwdriver
- T25 Torx Tamper-Resistant bit\* or driver
- 5/32" hex key
- 3/16" hex key
- 9/16" combo wrench or ratchet wrench
- Two (2) 7/16" combo wrenches or ratchet wrenches
- 5/16" combo wrench
- 3/16" or 1/4" punch\*
- Pry bar\*
- Hammer (dead-blow preferred)\*
- Two (2) weld clamps\* or C-clamps
- Two (2) straps with ratchet buckles\* (optional)
- 60" [1524 mm] long spreader tube\* or bar or 2x4 board (optional)

Be sure to read through all of the instructions in Section 5 before starting the process. Also see [Virtuoso Compression Video](#) from the Ascension website (see page 2).



## 5.1 Compressing the Lift

To compress the lift, complete the following steps in the order listed. Boxed step numbers correspond to boxed numbers in the referenced figures.


### **⚠ WARNING!**

***NEVER place your head or torso under any part of the platform.***

### **⚠ CAUTION!**

***Wear safety glasses at all times while performing the following procedures.***

1. Electrically isolate the lift in accordance with the instructions in Section 3.2 of this manual.
2. Prop the lower platform gate open using the hold-open washer on the door closer. Then use the hand pump in the right-hand machinery cabinet to raise the platform until the platform floor is approximately 15" [380 mm] off the ground.
3. Remove the platform skirt (*not* the gate skirt). See Section 3.4 of this manual for instructions.
- 4.** (Refer to Figure 5.1, next page) Open the upper platform gate and disconnect the dock plate tether from the gate by removing the two (2) Phillips #10 x 3/4" flat head screws that secure the footman's loop to the gate.
- 5.** (*step removed*).
6. (Refer to Figure 5.1) Disconnect the dock plate from the lift by removing the following fasteners:
  - 6.1** Two (2) Phillips #10 x 1/2" flat head screws that secure the dock plate hinge bracket to the platform floor in the back center of the floor.
  - 6.2** Four (4) 1/4-20 x 1/2" button head screws with lock washers that secure the dock plate hinge bracket to the platform sides, two (2) on each side. (Use a 5/32" hex key.)




**Figure 5.1 (Upper Landing Platform Gate View)**

7. Fold both floor sections up and secure them together in the raised position using duct tape or a similar method.

**⚠ CAUTION!**

***In the following step, stay clear of the platform when it is moving to avoid any pinching and/or crushing hazards.***

8. (Refer to Figures 5.1 & 5.2) Use the hand pump to raise the platform until it is approximately 36" [915 mm] off the ground. Remove the six (6) spring pins from the structural members at the back of the lift using a 3/16" or 1/4" punch. Once removed, use the hand pump to lower the platform back 15" [380 mm] above the ground.
9. (Refer to Figure 5.2) Use two (2) 7/16" combo wrenches or sockets to remove the four (4) 1/4-20 x 1" hex cap screws, four (4) 1/4-20 nuts, and eight (8) washers from the front base members.



**Figure 5.2 (Lower Landing Platform Gate View)**

10. (Refer to Figure 5.2) Install two (2) welding clamps or C-clamps in the location shown. These clamps should hold the vertical rails together securely.
11. (Refer to Figures 5.1 & 5.2) Use a 3/16" hex key to remove the eight (8) button head screws from the back base cross members.
12. If the four casters are not already installed, do so now. Position the caster pins such that they will not interfere with the floor for the last few inches of compression.
13. (Refer to Figure 5.2) Use a 9/16" combo wrench or socket to loosen the ten (10) 3/8-16 x 3/4" hex cap screws that hold the floor members together. These screws are located underneath the platform floor. They do not need to be completely removed, but they should be backed nearly all of the way out of the floor members.

**⚠ CAUTION!**

***As the sides of the platform are pushed together in Step 14 below, pull the flexible hoses at the back of the platform up into the empty space on the left side of the platform. See Figure 5.1. Failure to do so could result in damage to the hydraulic hoses.***

14. (Refer to Figure 5.2) With the upper and lower platform landing gates propped open using the hold-open washers on each door closer, push the sides of the platform together until the lift is narrowed to the required width. The lift can be pushed together manually by gripping at the locations shown. Or, if necessary, the straps provided with the Ascension Toolkit can be used, installed in the holes at the locations shown and routed underneath the platform. See Figure 5.6 on page 60 for instructions on operating the strap buckle.
15. (Refer to Figures 5.1 & 5.2) Install one (1) 5/16-18 x 5/8" button head cap screw (removed in Step 11) into the back base cross members and one (1) 1/4-20 x 1" hex cap screw with 1/4-20 nut (removed in Step 9) into the front base cross members in the locations shown.
16. (Refer to Figure 5.2) Remove the clamps from the back of the lift.

**⚠ CAUTION!**

***In the following step, stay clear of the platform when it is moving to avoid any pinching and/or crushing hazards.***

17. Use the hand pump to lower the platform to the ground and then raise the base off the ground. Take care that the swivel casters do not catch on the hydraulic cylinders as the platform is lowered. The lift can now be rolled through a doorway.

## 5.2 Expanding the Lift

To expand the lift, complete the following steps in the order listed. Boxed step numbers correspond to boxed numbers in the referenced figures.

### **⚠ WARNING!**

***NEVER place your head or torso under any part of the platform.***

### **⚠ CAUTION!**


***Wear safety glasses at all times while performing the following procedures.***

1. Electrically isolate the lift per the instructions in Section 3.2 of this manual.
2. Use the hand pump to raise the platform until the platform floor is approximately 15" [380 mm] off the ground.
- 3.** (Refer to Figure 5.3) Install two (2) welding clamps or C-clamps in the locations shown.
- 4.** (Refer to Figures 5.3 & 5.4) Remove the button head cap screw from the back cross members, and the hex cap screw and nut from the front cross members.

### **⚠ CAUTION!**

***As the sides of the platform are spread apart in Step 5 below, push the flexible hydraulic hoses into their normal position. See Figure 5.4. Failure to do so could result in damage to the hydraulic hoses.***


- 5.** Spread the platform apart to its normal width. Spread the lift manually by gripping at the locations shown in Figure 5.3. Or, if necessary, use the strap and spreader tube as shown in Figure 5.5. The paint on the upper surfaces of the small floor members is scored where the edges of the large floor members should be located when the platform is spread to the correct width.



NOT SHOWN FOR CLARITY: HYDRAULIC CYLINDERS & HOSES, FRONT LEFT SKIRT GUIDE & CASTER

**Figure 5.3 (Lower Landing Platform Gate View)**

6. (Refer to Figure 5.3) Tighten the ten (10) 3/8-16 x 3/4" hex cap screws which fasten the floor members together. Take special care to align the scored lines on the top of the smaller platform floor members with the edges of the larger platform floor members before tightening these screws.
7. (Refer to Figure 5.3) Use two (2) 7/16" wrenches to reinstall the four (4) 1/4-20 x 1" hex cap screws, four (4) 1/4-20 nuts, and eight (8) washers into the front base supports. Leave these screws and nuts very loose for now. The screws should be installed so that the screw heads are toward the front of the lift and the lock washers are under the nuts.
8. (Refer to Figure 5.4) Use a 3/16" hex key to turn the four (4) adjustment screws (two (2) on each side) at the back of the platform exactly three (3) full rotations counterclockwise.



**Figure 5.4 (Upper Landing Platform Gate View)**

9. (Refer to Figure 5.4) Thread the following fasteners into the back base cross members in the locations shown:

**9.1** one (1) 5/16-18 x 5/8 button head screw

**9.2** two (2) 5/16-18 x 1/2 button head screws


Tighten the screws and then back them off one (1) full turn counterclockwise. You may need to use a hammer or pry bar to align the holes in the cross members (refer to Figure 5.5).

10. (Refer to Figure 5.3) Thread the following fasteners into the back I-beam cross members in the locations shown:

**10.1** three (3) 5/16-18 x 5/8 button head screws

**10.2** two (2) 5/16-18 x 1/2 button head screws

Tighten the screws and then back them off one (1) full turn counterclockwise. You may need to use a hammer or pry bar to align the holes in the cross members (refer to figure 5.5).



**TO SPREAD THE LIFT CAR USING A STRAP AND SPREADER TUBE:**

1. BRACE THE SPREADER TUBE AGAINST THE BASE ANGLE AS SHOWN
2. WRAP THE STRAP AROUND THE FLOOR MEMBER SHOWN AND HOOK IT TO ITSELF
3. HOOK THE OTHER END OF THE STRAP TO THE SPREADER TUBE
4. OPERATE THE RATCHET BUCKLE TO PULL THE CAR APART

NOTE: THIS IS MOST EFFECTIVE AT THE BACK OF THE LIFT AS SHOWN, BUT CAN BE DONE AT ANY LOCATION FRONT-TO-BACK ON THE LIFT

**TO ALIGN THE HOLES IN THE I-BEAM CROSS MEMBERS AND THE BASE CROSS MEMBERS:**

1. SIDE-TO-SIDE: USE A HAMMER ON THE "HAMMER" POINTS SHOWN FOR THE I-BEAM AND BASE; OR, ATTACH THE RATCHET STRAP TO THE VERTICAL RAILS TO PULL THE SIDES TOGETHER
2. FRONT-TO-BACK: INSERT THE PRY BAR WHERE SHOWN

**Figure 5.5 (Upper Landing Platform Gate View)**


11. (Refer to Figure 5.3) Remove the two (2) clamps installed in Step 3.
12. (Refer to Figure 5.4) Install two (2) spring pins into the back base cross members.  
You may need to use a hammer or pry bar to align the holes in the cross members (refer to Figure 5.5). Then tighten the three (3) button head screws (from Step 9) in the back base cross members.
13. (Refer to Figure 5.3) Install one (1) spring pin into the horizontal I-beam cross members. You may need to use a hammer or pry bar to align the holes in the cross members (refer to Figure 5.5).



14. (Refer to Figure 5.4) Use a 3/16" hex key to turn the four (4) adjustment screws (two (2) on each side) at the back of the platform exactly three (3) full rotations clockwise.
15. (Refer to Figure 5.3) Install two (2) spring pins into the vertical I-Beam cross members. You may need to use a hammer or pry bar to align the holes in the cross members.
16. Tighten the five (5) button head screws (from Step 10) in the I-beam cross members.
17. (Refer to Figure 5.4) Reattach the dock plate to the platform by installing the following fasteners:
  - 17.1 Two (2) Phillips #10 x 1/2 flat head screws that secure the dock plate hinge bracket to the platform floor in the back center of the floor.
  - 17.2 Four (4) 1/4-20 x 1/2 button head screws with lock washers that secure the dock plate hinge bracket to the platform sides, two (2) on each side. (Use a 5/32" hex key.)
18. (step removed).
19. (Refer to Figure 5.4) Reconnect the dock plate tether to the upper platform gate using the footman's loop and two (2) #10 x 3/4 flat head screws.
20. Tighten the hex cap screws installed in Step 7 above.
21. Reinstall the platform safety skirt. Refer to Section 3.4 of this manual.
22. Return the platform floor to its normal position and pump the lift onto its wheels.
23. Move the lift to the desired location and set it up according to the instructions in the *Operating Manual* and then verify the correct operation of the lift as described in Section 5.3.

**⚠ WARNING!**

***Verify the correct operation of the lift, as described in Section 5.3, before using the lift. Failure to do so could result in serious injury to the user.***



**Figure 5.6 Ratchet buckle instructions (when using Ascension Toolkit)**

### **5.3 Verification of Operation**

Before the lift can be used to transport passengers, its correct operation must be verified. After the lift has been set up in the desired location, its operation must satisfy the following requirements:

1. The lift operates as described in the Setup Instructions of the *Operating Manual*.
2. The platform will not move up or down if either gate is open.
3. The lower platform gate is locked when the lift is more than 2" [50 mm] off the ground.

If the operation of the lift does not satisfy the above conditions, review and/or repeat the reassembly steps as necessary to correct the problem. Additionally, the troubleshooting tips in Section 6 of this manual may be useful in restoring the lift to operating condition.

#### **WARNING!**

***DO NOT use the lift until its correct operation has been verified. It is absolutely imperative for the safety of the lift passenger that the lift is functioning correctly. If any of the above conditions is not met, and the problem cannot be corrected by reviewing or repeating the reassembly steps, contact Ascension immediately.***

## SECTION 6 Troubleshooting


The table below presents the necessary information to perform basic troubleshooting on the lift. The numbers in the Section column refer to sections within this manual. For the sake of completeness, many of the items in this table are of a setup and operational nature and are not specifically addressed in this manual. Please refer to the *Operating Manual* for these items.

Problem	Possible Cause	Remedy	Section
Platform will not raise or lower	Electrical cord is not plugged in	Plug in electrical cord	N/A
	Emergency Stop is depressed	Turn clockwise to reset	3.10
	Lift is turned off	Turn the lift on	3.11
	GFCI is tripped	Reset the GFCI	3.21
	Cord disconnect switch is OFF	Turn disconnect switch to ON	3.21
	No power at the service outlet	Check breaker for the outlet or plug electrical cord into another outlet	N/A
	One or both gates are open	Close both gates	N/A
	Lift is set up on incline greater than 5%	Move lift to level surface	3.13
	Lower platform gate switch is out of adjustment	Adjust the lower platform gate switch	3.7
	Upper platform gate switch is out of adjustment	Adjust the upper platform gate switch actuator	3.8
	Component failure	Electrical testing -- possible component replacement	4.2
Platform will raise but will not lower	Person or object is leaning against the safety skirt	Return the skirt to its normal (relaxed) position	3.15
	Operating switch failure	Try alternate operating switch; replace switch if necessary	3.10
	Directional valve failure	Replace directional valve	3.16
	Relay module failure	Electrical testing -- possible component replacement	4.3

<b>Problem</b>	<b>Possible Cause</b>	<b>Remedy</b>	<b>Section</b>
Platform will not go more than 2" [50 mm] off the ground	Lower platform gate locking rod is not engaging	Adjust the upper lock rollers	3.9
	Locking rod switch failure	Test locking rod switch & replace if necessary	3.9
	Lower terminal switch out of adjustment	Adjust lower terminal switch	3.6
Platform will not go more than 10" [250 mm] off the ground	Lift is in transport mode	Set the upper height knob properly per the <i>Operating Manual</i>	N/A
Platform "coasts" downward over an extended period of time	Counterbalance valve malfunction	Replace counterbalance valve	3.16
Platform does not stop automatically at the upper landing	Upper height knob is not set correctly	Set the upper height knob properly per the <i>Operating Manual</i>	N/A
	Upper stop switch failure	Replace upper stop switch	3.6
	Upper stop mechanism is out of adjustment	Adjust upper stop mechanism	3.6
Motor runs but platform does not raise	Hydraulic fluid level is low	Fill hydraulic fluid reservoir	2.1
	Main hydraulic shut-off closed	Open shut-off valve	3.16
	Break in hydraulic circuit	Repair break and fill hydraulic fluid reservoir	2.1
	Directional valve stuck open	Replace directional valve	3.16
	Platform is overloaded	Reduce load on platform until load is equal to or less than the rated load	N/A

Notes:





**ascension®**  
**WHEELCHAIR LIFTS**  
A DIVISION OF AGM